

INDEKS NOŚNOŚCI

(wg standardu ETRTO)

LI	kg	LI	kg	LI	kg	LI	kg
60	250	90	600	120	1400	150	3350
61	257	91	615	121	1450	151	3450
62	265	92	630	122	1500	152	3550
63	272	93	650	123	1550	153	3650
64	280	94	670	124	1600	154	3750
65	290	95	690	125	1650	155	3875
66	300	96	710	126	1700	156	4000
67	307	97	730	127	1750	157	4125
68	315	98	750	128	1800	158	4250
69	325	99	775	129	1850	159	4375
70	335	100	800	130	1900	160	4500
71	345	101	825	131	1950	161	4625
72	355	102	850	132	2000	162	4750
73	365	103	875	133	2060	163	4875
74	375	104	900	134	2120	164	5000
75	387	105	925	135	2180	165	5150
76	400	106	950	136	2240	166	5300
77	412	107	975	137	2300	167	5450
78	425	108	1000	138	2360	168	5600
79	437	109	1030	139	2430	169	5800
80	450	110	1060	140	2500	170	6000
81	462	111	1090	141	2575	171	6150
82	475	112	1120	142	2650	172	6300
83	487	113	1150	143	2725	173	6500
84	500	114	1180	144	2800	174	6700
85	515	115	1215	145	2900	175	6900
86	530	116	1250	146	3000	176	7100
87	545	117	1285	147	3075	177	7300
88	560	118	1320	148	3150	178	7500
89	580	119	1360	149	3250	179	7750

SYMBOL PRĘDKOŚCI

(wg standardu ETRTO)

Symbol prędk.	Prędk. (km/h)	Symbol prędk.	Prędk. (km/h)
E	70	R	170
F	80	S	180
G	90	T	190
J	100	U	200
K	110	H	210
L	120	V	240
M	130	W	270
N	140	Y	300
P	150	Z	PONAD 240*
Q	160		

* Bliższe informacje u producenta.

KATEGORIA PRĘDKOŚCI

OZNACZENIA KAT. PRĘDKOŚCI	LIMIT PRĘDKOŚCI DLA OPONY (km/h)
Radialna	
ZR	ponad 240